

Schluter Shower System Installation Checklist

Required System Components

- KERDI waterproofing membrane
- KERDI-SHOWER-T prefabricated shower tray
- KERDI-DRAIN or KERDI-LINE
- KERDI-BAND and sealing corners
- KERDI pipe seals and niche (optional)
- KERDI-BOARD (for walls/benches, optional)

Tools & Supplies Checklist

- Unmodified thin-set mortar
- Notched trowel (1/4" x 3/16")
- Utility knife and straight edge
- Mixing bucket and margin trowel
- Tape measure, level, pencil/marker
- Sponge, roller, drywall knife

Step-by-Step Installation Process

- 1. Prepare subfloor and ensure it's level and clean
- 2. Dry-fit tray and mark drain location
- 3. Mix and apply thin-set mortar
- 4. Embed tray and set drain assembly in place
- 5. Apply mortar and install KERDI membrane on walls and floor
- 6. Seal all corners and seams with KERDI-BAND
- 7. Install accessories: niches, pipe seals, benches
- 8. Inspect overlaps and perform optional flood test
- 9. Begin tiling immediately after waterproofing