



Portable Hudson sprayer Instructions :

- Mix Truck Wash at a 4 with water in sprayer.
- Mist surface with water before you apply the Truckwash.
- Spray Truck Wash generously over a 10'x10' area. Then immediately use soft brush to scrub area.
- Once area appears clean rinse with water. Streaking may occur if not rinsed properly. (Use a brush while rinsing to remove dried on foam/brush marks)
- 5. Repeat steps as necessary.

CONTACT US

Concrete Chemicals, Inc. 25385 Hwy 169

Zimmerman, MN 55398

844.289.2532

ConcreteChemicals.com



Foaming Pump Instructions:

Truck Wash is sold in a concentrate, we recommend it be mixed 4-1 with water before applying. Truck Wash was designed specifically for the Ready-Mix industry and is safe for most surfaces, however it can leave streaking on some plastics and some aluminums, a small area should be sprayed and tested first.

- 1. Lightly mist areas to be washed with water (This will help prevent foam from drying to fast) and apply Truck Wash with foaming wand from your attached pump to ready-mix drum, fenders then tires and allow to activate for approx. 5 minutes. (Apply light mists of water to foam on hot days to prevent drying). Cab does not require 5 minute activation time. Use full strength CLEAN-OFF concrete remover for the back of the truck. * See CLEAN-OFF instructions for more detail.
- 2. Use a brush to scrub areas where foam has been applied.
- 3. Rinse with water. Streaking may occur if not rinsed properly. (Use a brush while rinsing to remove dried on foam/brush marks) The more it is used, the easier trucks are to clean.
- 4. Repeat steps 1 3 as necessary.
- *Newer Trucks can dilute Truck Wash by up to 8-1 in a 5 gallon pail prior to step 1 above and can use pick up hose from tote to foam truck. (This will help prevent streaking on surfaces that have not been damaged by acid washing.)