

Hot Tub Winterization

- 1) Drain tub
- 2) Take out jets
- 3) Remove unions at pump and drain cap in bottom of tub
(centre)
- 4) Take shop vac and suck out all of the lines, jets and pump
- 5) Empty shop vac
- 6) Out vac on blow and blow all lines out
- 7) Suck any leftover water out, for example skimmer
- 8) Take r.v. antifreeze and pour down every jet hole- in drain,
skimmer and pump
- 9) Put back together
- 10) Put cover on and tarp