

Category: Micron Film
System: Liquid Grip
Product: Liquid Grip™ (2-step)
Surface: Any surface



1) Thoroughly clean the flooring to be coated, removing all existing wax and sealers prior to application of the Liquid Grip products. One can use the Deep Clean product as follows below to ensure proper cleaning.

2) Deep Clean (13.5 alkaline cleaner). Mix Deep Clean with water (16oz. per gallon) and apply liberally to the floor. Let solution dwell for 15 minutes. Scrub with floor machine with uneven Tile and Grout brush and pick-up slurry with high quality wet/vac up. Confirm that cleaning solution is removed from grout lines.

3) Dry tack the floor with NeverStrip Tack Cloth

4) Shake well, and then apply Step-1 with supplied high-density foam rollers at approximately 1,000-1,500 SF per quart to areas that are subject to submerged water, or constantly wet. Step-1 has aggregate which tends to settle on bottom of container. **Pour the entire contents of a Step 1 quart into a sufficiently sized paint tray or tub to allow the aggregate mix to be fully available.** Dip and roll into the tray to saturate the roller for each application.

5) Shake lightly, and then apply Step-2 with supplied high-density foam rollers at approximately 1,000-1,500 SF per quart to areas that are subject to submerged water, or constantly wet. Step-2 doesn't have aggregate and acts as a top coat.

Important Notes:

- Additional instructions on Product Data Sheets and other resources are available at www.neverstrip.com.
- For Kitchen Quarry Tile floors, please consult with your NeverStrip Technical Advisor for the latest High Solids Urethane options for these demanding environments.



Micron Floor Coatings for the New Millennium
neverstrip.com

