

# MICRON - REFRESH DULL, PREVIOUSLY POLISHED CONCRETE

**System:** Micron - Refresh dull, previously polished concrete

**Products:** Deep Clean, Stone, Terrazzo & Concrete Seal, Shine Diamond Pad

**Surfaces:** Previously Polished Concrete



## Concrete Refresh System Instructions

This system is designed to refresh concrete that was previously polished with diamond tooling but has become dull. It is not intended for restoring deeply scratched polished concrete, as additional restorative processes are required for such floors.

### Steps:

#### 1. Prepare the Cleaning Solution

- Mix NeverStrip **Deep Clean** with water at a ratio of 4 oz. of Deep Clean per gallon of water.
- Apply the solution to the floor, keeping it wet for 15 minutes before scrubbing.

#### 2. Scrub the Floor

- Use a green pad to scrub the floor.
- Extract the solution and rinse the floor with water.

#### 3. Dry the Floor

- Allow the floor to dry completely.

#### 4. Apply Stone, Terrazzo & Concrete Seal

- On highly reflective surfaces, NeverStrip strongly recommends the use of the 3M Microfiber Applicator Pad
- Two Applications:
  - Spread rate: 4,000 - 5,000 sq. feet per gallon/application.
  - The first application may have less coverage per gallon.

### Application methods:

Use a quality **Microfibre Spray Mop Applicator** (using [this method](#)) or a standard garden pump sprayer with a dripless brass tip.

- Pre-dampen the microfibre pad with the sealer before application.
- If using a pump sprayer, spray just ahead of spreading.
- Avoid too much product; if the product appears white, it is over-applied.
- Avoid “playing” with the sealer too much.
- Do NOT pull the product from one section to another.
- Spread product onto adjoining sections by a couple of inches to avoid skips.
- Allow 10-15 minutes for drying before applying the next coat or resuming typical commercial traffic.
- Allow 25 minutes of dry time if burnishing the last application.

# MICRON - REFRESH DULL, PREVIOUSLY POLISHED CONCRETE

Page 2

## Caution:

- Keep water off the floor for **8 hours**.

## Post-Application Maintenance:

- Scrub the floor with a red pad and Micron Clean (2 oz./gallon of water), then burnish during the first 1-2 weeks to remove marks/scuffs/surface scratches from the sealer during its initial curing.

## Additional Resources:

- Product Data Sheets and other resources are available at [www.neverstrip.com](http://www.neverstrip.com).
- Click [here](#) for Cleaning and Maintenance instructions.

