

Category: Micron

System: Micron VCT

Products: NeverStrip Micron Primer - Vinyl Seal or Micron All Surface Sealer-
220 Grit Coarse pad - 800 Grit Condition Pad - 8000 Grit Burnish Pad

Surface: VCT



Step 1: Floor Preparation

Strip all floor finish:

- Use NeverStrip Floor Finish Eliminator on non-urethane fortified/modified floor finishes.
- Plan for 125% effort compared to stripping for reapplying floor finish.
- Micron Sealers are clear and thin, so they won't hide old floor finish, soil, or marks.

Step 2: Smoothing the Surface

- Use an auto scrubber, a 175-rpm, or square scrub type floor machine with an 800 grit Condition Pad in the final scrub/rinse step.
- This step smooths and evens the VCT, resulting in a higher quality finish with Micron Sealers.
- Allow floor to dry completely before commencing Step 3.

Step 3: Apply Micron Primer

Two Applications:

- Spread rate: 3,000 sq. feet per gallon/application.
 - Pre-dampen the microfiber pad by spraying Micron Primer onto it.
 - Apply the first application heavier than the second.
 - Work in sections 3' x 6':
 - Spray the product onto the section and spread with a microfiber pad using this method.
- NOTE: Micron Primer goes down at twice the rate of that shown in video.
- If working with a partner, the spraying should occur just before spreading.

Important Tips:

- Do NOT pull product from one section to another.
- Do NOT overwork the product.
- Overlap adjoining sections by a couple of inches to avoid skips.
- Allow 25 minutes for drying before applying the next coat.

Step 4: Apply Vinyl Seal or Micron All Surface Sealer

Two Applications:

- Spread rate: 5,000 sq. feet per gallon/application.
- Pre-dampen the microfiber pad by spraying product onto it.

Continued on following page

- Work in sections 3' x 6':
- Spray product onto the section and immediately spread with a microfiber pad using this method.
- Apply a thin coat; thinner is better. The Vinyl Seal should not appear white during application.
- If working with a partner, the spraying should occur just before spreading.

Important Tips:

- Do NOT pull product from one section to another.
- Do NOT overwork the product.
- Overlap adjoining sections by a couple of inches to avoid skips.
- Allow 10 minutes for drying before applying the next coat or allowing traffic.

Step 5: Burnish for Higher Shine (Optional)

- Wait 25 minutes after final Vinyl Seal or Micron All Surface Sealer application.
- Burnish with NeverStrip 8000 Grit Burnish Pad using an electric or propane burnisher.

Caution:

Keep water off the floor for 8 hours.

Post-Application Maintenance:

Scrub the floor with an 8000 Grit Clean and Buff Pad and Micron Clean (2 oz./gallon of water), then burnish during the first 1-2 weeks to remove marks/scuffs/surface scratches from the sealer during its initial curing.

Additional Resources:

Product Data Sheets and other resources are available at www.neverstrip.com.
Click [here](#) for Cleaning and Maintenance instructions.



neverstrip.com