

# MICRON HIGH TRACTION WET FLOORS with Liquid Grip

**System:** Micron Liquid Grip  
**Products:** NeverStrip Liquid Grip - Micron Sealer  
**Surfaces:** Any Non-Carpet Surface



## Liquid Grip Product Overview

### Product Description:

- **Liquid Grip** is part of NeverStrip Floor Coatings' Micron Family of Floor Sealers.
- Designed to provide **high traction** in wet environments.
- **Ideal Applications:** Locker rooms, shower floors, pool decks, exterior stamped concrete, and ramps. concrete, and ramps.
- **Applicable on:** Any non-carpet flooring.

### Key Characteristics:

- Purpose: Higher wet floor traction, not intended for aesthetics.
- **Cleaning Considerations:**
  - Use a **soft brush** with NeverStrip Micron Clean for cleaning.
  - Avoid scrubbing pads, non-soft brushes, or auto-scrubbers with squeegees, as these may remove Liquid Grip's aggregate.
- **Maintenance:**
  - Occasional reapplication is necessary to maintain traction, with an annual reapplication anticipated.
  - Coverage per kit: **350-400 sq. feet**, depending on application technique.
  - Kit includes **one quart of Step 1, one quart of Step 2, and two 9" high-density foam rollers.**

## Application Process

### Step 1: Surface Preparation

- Remove any existing floor finish, sealers, or coatings.
- **Deep Clean Mixture:** Mix 4 oz. of NeverStrip Deep Clean per gallon of water.
- Apply the solution to the floor and let it sit for 15 minutes, keeping it wet.
- Scrub the floor with a green pad, extract, rinse with water, and allow the floor to dry.

### Step 2: Application of Floor-Specific Micron Sealer

- Relevant to the floor being addressed - **Apply 1 coat of either Tile Seal, Rubber Seal, Stone, Terrazzo, and Concrete Seal or Vinyl Seal** with a Spray Mop Applicator
- Allow 10 minutes before proceeding to Step 3.

### Step 3: Application of [Liquid Grip Step 1](#)

- Shake the Step 1 quart container well.
- Pour the entire contents into a **7-gallon application tub.**
- **Dip and Roll Application:**
  - Apply in 3' x 3' sections per dip of the 9" roller cover.
  - Liberally overlap prior sections.
  - **Important:** Resuspend the aggregate with each dip by "sloshing" the product in the tub to ensure even distribution.
- Allow Step 1 to dry for **20-30 minutes** before applying Step 2. Wear clean booties.

# MICRON HIGH TRACTION WET FLOORS with Liquid Grip

Page 2

## Step 4: Dry Roll Step 1

- The **Liquid Grip Step 1** Product will often separate (like oil and water) during its application.
- This appearance is eliminated by an optional dry rolling of the still wet but drying Liquid Grip Step 1 Product with a new, dry, 3/8" nap microfiber roller cover about 5-10 minutes after applying the Step 1 Product.
- The roller cover used with this dry rolling process is provided as part of the Liquid Grip Kit. It is helpful for whomever is performing the dry rolling process to wear golf shoes with plastic golf spikes or equivalent, so this person can, as needed, walk into/onto the wet Liquid Grip.
- The dry rolling process can be done by the same person who applies the Liquid Grip Step 1 Product or can be performed by a second individual.
- Allow Step 1 Product to dry at least 30 minutes before applying Step 2 Product.

## Step 5: Application of Step 2

- Apply Step 2 using the same method as Step 1.
- No need to resuspend aggregate as there is none in Step 2.
- The floor can be put back into service **30 minutes** after applying Step 2.
- **Caution:** Keep water off the floor for **8 hours**.

## Storage and Reuse:

- Pour any unused Step 1 or Step 2 products back into their original containers.
- Use the remaining product within **6 months**. Keep the lid tightly closed.

## Additional Resources:

- Product Data Sheets and other resources are available at [www.neverstrip.com](http://www.neverstrip.com).
- Click [here](#) for Cleaning and Maintenance instructions.

