

Ferrari Hypercars

Legenda / Key:

DIAG = Diagnosi / Diagnosis

DTC = Lettura errori / Fault codes reading

PAR = Parametri / Parameters

ATT = Verifica componenti (diagnosi attiva) / Check components (active diagnosis)

COD = Adattamento e codifica / Adaptation and coding

X = Supportato / Supported

A = Auto-riconoscimento (disponibile in funzione della versione di centralina presente sul veicolo)

A = Self-recognition (depends on the version of the ecu installed on the vehicle)

Daytona SP3 (F150BD)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive driving beam left	X	X	X		X
Adaptive driving beam right	X	X	X		X
Body computer	X	X	X		X
Climate	X	X	X		X
Dual camera 2	X	X	X		X
E-latch left	X	X	X		X
E-latch right	X	X	X		X
Electrical powered hydraulic steering	X	X	X		X
Eyelids	X	X	X	X	X
F1 commands	X		X		X
Gearbox	X	X	X		X
ION unit UDS left	X	X	X		X
ION unit UDS right	X	X	X		X
ION unit left	X	X	X		X
ION unit right	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X		X
Lifter	X	X	X	X	X
Light control unit	X	X	X		X
Mirror and external light control	X	X	X		X
NAB - Airbag	X	X	X	X	X
NCML - Engine control module left / NCML_21	X	X	X	X	X
NCMR - Engine control module right / NCMR_21	X	X	X	X	X
NFR - Brake	X	X	X		X
OCTO unit left	X	X	X		X
OCTO unit right	X	X	X		X
Parking Brake	X	X	X	X	X
Parking sensor	X	X	X		X
Passive entry	X	X	X		X
Power Steering	X	X	X		X
Steering wheel	X	X	X		X
Suspension	X	X	X		X
Tire pressure	X	X	X		X
Window lifter module left	X		X		X
Window lifter module right	X		X		X
eCall	X	X	X		X

F40 (Cat. EUR)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Marelli IAW 04F/50 bank 1 / MARELLI_IAW_4F50_B1	X	X	X	X	X
Marelli IAW 04F/50 bank 2 / MARELLI_IAW_4F50_B2	X	X	X	X	X

F40 (Cat. USA)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Marelli IAW 04F/40 bank 1 / MARELLI_IAW_4F40_B1	X	X	X	X	X
Marelli IAW 04F/40 bank 2 / MARELLI_IAW_4F40_B2	X	X	X	X	X

F40 (No Cat.)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Marelli IAW 04F.07 bank 1 / MARELLI_IAW_4F07_B1	X	X	X	X	X
Marelli IAW 04F.07 bank 2 / MARELLI_IAW_4F07_B2	X	X	X	X	X

LaFerrari (F150)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Aero Wings	X	X	X	X	X
Body computer	X	X	X	X	X
Climate control	X	X	X	X	X
Driver's door	X	X	X	X	X
Electrical Power Hydraulic Steering	X	X	X		X
Gearbox system	X	X	X		X
Headlight	X	X	X	X	X
High Voltage Battery	X	X	X	X	X
Hybrid High Power Unit	X	X	X		X
Hybrid Low Power Unit	X	X	X		X
Infotainment	X	X	X		X
Infotainment canbox	X	X	X		X
Instrument cluster	X	X	X	X	X
Ion unit left	X	X	X		X
Ion unit right	X	X	X		X
Lifter	X	X	X	X	X
NAB - Airbag	X	X	X	X	X
NCML - Engine left / NCML_07	X	X	X	X	X
NCMR - Engine right / NCMR_07	X	X	X	X	X
NFR - Brake system	X	X	X		X
Parking brake	X	X	X	X	X
Parking sensor	X	X	X	X	X
Passenger door	X	X	X	X	X
Power steering	X	X	X		X
Steering wheel	X	X	X	X	X
Suspension	X	X	X		X
Telemetry	X	X	X	X	X
Tire pressure	X	X	X	X	X

LaFerrari Aperta (F150 Aperta)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Aero Wings	X	X	X	X	X
Body computer	X	X	X	X	X
Climate control	X	X	X	X	X
Driver's door	X	X	X	X	X
Electrical Power Hydraulic Steering	X	X	X		X
Gearbox system	X	X	X		X
Headlight	X	X	X	X	X
High Voltage Battery	X	X	X	X	X
Hybrid High Power Unit	X	X	X		X
Hybrid Low Power Unit	X	X	X		X
Infotainment	X	X	X		X
Infotainment canbox	X	X	X		X

Instrument cluster	X	X	X	X	X
Ion unit left	X	X	X		X
Ion unit right	X	X	X		X
Lifter	X	X	X	X	X
NAB - Airbag	X	X	X	X	X
NCML - Engine left / NCML_07	X	X	X	X	X
NCMR - Engine right / NCMR_07	X	X	X	X	X
NFR - Brake system	X	X	X		X
Parking brake	X	X	X	X	X
Parking sensor	X	X	X	X	X
Passenger door	X	X	X	X	X
Power steering	X	X	X		X
Steering wheel	X	X	X	X	X
Suspension	X	X	X		X
Telemetry	X	X	X	X	X
Tire pressure	X	X	X	X	X

Monza SP1 (F176)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body computer	X	X	X	X	X
Camera	X	X	X		X
Climate	X	X	X	X	X
Electrical powered hydraulic steering	X	X	X		X
Gearbox	X	X	X		X
Headlight	X	X	X	X	X
ION unit left	X	X	X		X
ION unit right	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X	X	X
Instrument cluster control	X	X	X	X	X
Lifter	X	X	X	X	X
Multimedia control	X	X	X	X	X
NAB - Airbag	X	X	X	X	X
NCMR - Engine left / NCML_16	X	X	X	X	X
NCMR - Engine right / NCMR_16	X	X	X	X	X
NFR - Brake	X	X	X	X	X
Parking brake	X	X	X	X	X
Parking sensor	X	X	X	X	X
Passive entry	X	X	X	X	X
Rear wheel steering left	X	X	X		X
Rear wheel steering right	X	X	X		X
Steering wheel	X	X	X	X	X
Suspension	X	X	X		X
Tire pressure	X	X	X		X

Monza SP2 (F176)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body computer	X	X	X	X	X
Camera	X	X	X		X
Climate	X	X	X	X	X
Electrical powered hydraulic steering	X	X	X		X
Gearbox	X	X	X		X
Headlight	X	X	X	X	X
ION unit left	X	X	X		X
ION unit right	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X	X	X
Instrument cluster control	X	X	X	X	X

Lifter	X	X	X	X	X
Multimedia control	X	X	X	X	X
NAB - Airbag	X	X	X	X	X
NCMR - Engine left / NCML_16	X	X	X	X	X
NCMR - Engine right / NCMR_16	X	X	X	X	X
NFR - Brake	X	X	X	X	X
Parking brake	X	X	X	X	X
Parking sensor	X	X	X	X	X
Passive entry	X	X	X	X	X
Rear wheel steering left	X	X	X		X
Rear wheel steering right	X	X	X		X
Steering wheel	X	X	X	X	X
Suspension	X	X	X		X
Tire pressure	X	X	X		X

Purosangue (F175)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive driving beam left	X	X	X		X
Adaptive driving beam right	X	X	X		X
Audio domain control	X	X	X		X
Body computer	X	X	X	X	X
Chassis domain control	X	X	X	X	X
Climate	X	X	X	X	X
Dimmable glass	X	X	X		X
Driver assistance system module	X	X	X	X	X
Driver seat	X	X	X	X	X
E-latch left	X	X	X	X	X
E-latch rear left	X	X	X	X	X
E-latch rear right	X	X	X	X	X
E-latch right	X	X	X	X	X
F1 commands	X	X	X	X	X
Gearbox	X	X	X	X	X
Haptic lane feedback system	X	X	X		X
Head up display	X	X	X	X	X
Headlights	X	X	X		X
ION unit K left	X	X	X		X
ION unit K right	X	X	X		X
ION unit left	X	X	X	X	X
ION unit right	X	X	X	X	X
Infotainment	X	X	X	X	X
Instrument panel	X	X	X	X	X
LIN central ceiling	X	X	X	X	X
Left blind spot system	X	X	X	X	X
Lifter	X	X	X	X	X
Magic knob front	X	X	X	X	X
Magic knob rear	X	X	X	X	X
Magic surface front	X	X	X	X	X
Mild hybrid voltage battery	X	X	X		X
Mirror and external light control	X	X	X	X	X
NAB - Airbag	X	X	X	X	X
NCML - Engine control module left / NCML	X	X	X	X	X
NCMR - Engine control module right / NCMR	X	X	X	X	X
NFR - Brake	X	X	X	X	X
OCTO unit left	X	X	X	X	X
OCTO unit right	X	X	X	X	X
Parking sensor	X	X	X		X
Passenger display	X	X	X		X
Passenger seat	X	X	X	X	X
Passive entry	X	X	X	X	X
Power control unit	X	X	X		X
Power liftgate	X	X	X	X	X

Power steering	X	X	X	X	X
Rear climate	X	X	X	X	X
Rear seat left	X	X	X	X	X
Rear seat right	X	X	X	X	X
Rear wheel steering master (rh)	X	X	X		X
Rear wheel steering slave (lh)	X	X	X		X
Right blind spot system	X	X	X	X	X
Steering wheel	X	X	X	X	X
Surround view	X	X	X	X	X
Suspension front left	X	X	X		X
Suspension front right	X	X	X		X
Suspension rear left	X	X	X		X
Suspension rear right	X	X	X		X
Tire pressure	X	X	X		X
Window lifter left	X		X		X
Window lifter rear left	X		X		X
Window lifter rear right	X		X		X
Window lifter right	X		X		X
Wireless charger	X	X	X	X	X
Wireless charger rear	X	X	X	X	X
Yaw sensor	X	X	X	X	X
eCall	X	X	X	X	X

SF90 Stradale (F173)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive driving beam left	X	X	X		X
Adaptive driving beam right	X	X	X		X
Aero wings	X	X	X		X
Amplifier	X	X	X		X
Body computer	X	X	X		X
Camera	X	X	X		X
Climate	X	X	X		X
Dogring left	X	X	X		X
Dogring right	X	X	X		X
Driver assistance system module	X	X	X		X
Driver seat	X	X	X		X
E-latch left	X	X	X		X
E-latch right	X	X	X		X
Electrical powered hydraulic steering	X	X	X		X
F1 commands	X		X		X
Gearbox	X	X	X		X
Haptic lane feedback system	X	X	X		X
Head up display	X	X	X		X
High voltage battery	X	X	X		X
ION unit	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X		X
Inverter P2	X	X	X		X
Inverter P4L	X	X	X		X
Inverter P4R	X	X	X		X
Left blind spot system	X	X	X	X	X
Lifter	X	X	X	X	X
Light control unit	X	X	X		X
Mirror and external light control	X	X	X		X
NAB - Airbag	X	X	X	X	X
NCML - Engine control module / NCML_17	X	X	X	X	X
NCMR - Engine control module / NCMR_17	X	X	X	X	X
NFR - Brake	X	X	X		X
OCTO unit left	X	X	X		X
OCTO unit right	X	X	X		X
On board charger	X	X	X		X

Parking sensor	X	X	X	X	X
Passenger interactive panel	X	X	X		X
Passenger seat	X	X	X		X
Passive entry	X	X	X		X
Power control unit	X	X	X		X
Right blind spot system	X	X	X	X	X
Steering wheel	X	X	X		X
Surround view camera	X	X	X		X
Suspension	X	X	X		X
Tire pressure	X	X	X		X
Warning sound/ AVAS	X	X	X		X
Window lifter module left	X		X		X
Window lifter module right	X		X		X
eCall	X	X	X		X

SF90 Stradale Spider (F173)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive driving beam left	X	X	X		X
Adaptive driving beam right	X	X	X		X
Aero wings	X	X	X		X
Amplifier	X	X	X		X
Body computer	X	X	X		X
Camera	X	X	X		X
Climate	X	X	X		X
Dogring left	X	X	X		X
Dogring right	X	X	X		X
Driver assistance system module	X	X	X		X
Driver seat	X	X	X		X
E-latch left	X	X	X		X
E-latch right	X	X	X		X
Electrical powered hydraulic steering	X	X	X		X
F1 commands	X		X		X
Gearbox	X	X	X		X
Haptic lane feedback system	X	X	X		X
Hardtop	X	X	X		X
Head up display	X	X	X		X
High voltage battery	X	X	X		X
ION unit	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X		X
Inverter P2	X	X	X		X
Inverter P4L	X	X	X		X
Inverter P4R	X	X	X		X
Left blind spot system	X	X	X	X	X
Lifter	X	X	X	X	X
Light control unit	X	X	X		X
Mirror and external light control	X	X	X		X
NAB - Airbag	X	X	X	X	X
NCML - Engine control module / NCML_17	X	X	X	X	X
NCMR - Engine control module / NCMR_17	X	X	X	X	X
NFR - Brake	X	X	X		X
OCTO unit left	X	X	X		X
OCTO unit right	X	X	X		X
On board charger	X	X	X		X
Parking sensor	X	X	X	X	X
Passenger interactive panel	X	X	X		X
Passenger seat	X	X	X		X
Passive entry	X	X	X		X
Power control unit	X	X	X		X
Right blind spot system	X	X	X	X	X
Steering wheel	X	X	X		X

Surround view camera	X	X	X		X
Suspension	X	X	X		X
Tire pressure	X	X	X		X
Warning sound/ AVAS	X	X	X		X
Window lifter module left	X		X		X
Window lifter module right	X		X		X
eCall	X	X	X		X

SF90 XX Stradale (F173VS)

<i>Centralina / ecu</i>	<i>DIAG</i>	<i>DTC</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive driving beam left	X	X	X		X
Adaptive driving beam right	X	X	X		X
Aero wings	X	X	X		X
Amplifier	X	X	X		X
Body computer	X	X	X		X
Camera	X	X	X		X
Climate	X	X	X		X
Dogring left	X	X	X		X
Dogring right	X	X	X		X
Driver assistance system module	X	X	X		X
E-latch left	X	X	X		X
E-latch right	X	X	X		X
Electrical powered hydraulic steering	X	X	X		X
F1 commands	X		X		X
Gearbox	X	X	X		X
Haptic lane feedback system	X	X	X		X
Head up display	X	X	X		X
High voltage battery	X	X	X		X
ION unit	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X		X
Inverter P2	X	X	X		X
Inverter P4L	X	X	X		X
Inverter P4R	X	X	X		X
Lifter	X	X	X	X	X
Light control unit	X	X	X		X
Mirror and external light control	X	X	X		X
NAB - Airbag	X	X	X	X	X
NCML - Engine control module / NCML_17	X	X	X	X	X
NCMR - Engine control module / NCMR_17	X	X	X	X	X
NFR - Brake	X	X	X		X
OCTO unit left	X	X	X		X
OCTO unit right	X	X	X		X
On board charger	X	X	X		X
Parking sensor	X	X	X	X	X
Passenger interactive panel	X	X	X		X
Passive entry	X	X	X		X
Power control unit	X	X	X		X
Steering wheel	X	X	X		X
Surround view camera	X	X	X		X
Suspension	X	X	X		X
Tire pressure	X	X	X		X
Warning sound/ AVAS	X	X	X		X
Window lifter module left	X		X		X
Window lifter module right	X		X		X
eCall	X	X	X		X

SF90 XX Stradale Spider (F173VS)

Centralina / ecu	DIAG	DTC	PAR	ATT	COD
Adaptive driving beam left	X	X	X		X
Adaptive driving beam right	X	X	X		X
Aero wings	X	X	X		X
Amplifier	X	X	X		X
Body computer	X	X	X		X
Camera	X	X	X		X
Climate	X	X	X		X
Dogring left	X	X	X		X
Dogring right	X	X	X		X
Driver assistance system module	X	X	X		X
E-latch left	X	X	X		X
E-latch right	X	X	X		X
Electrical powered hydraulic steering	X	X	X		X
F1 commands	X		X		X
Gearbox	X	X	X		X
Haptic lane feedback system	X	X	X		X
Hardtop	X	X	X		X
Head up display	X	X	X		X
High voltage battery	X	X	X		X
ION unit	X	X	X		X
Infotainment	X	X	X		X
Instrument cluster	X	X	X		X
Inverter P2	X	X	X		X
Inverter P4L	X	X	X		X
Inverter P4R	X	X	X		X
Lifter	X	X	X	X	X
Light control unit	X	X	X		X
Mirror and external light control	X	X	X		X
NAB - Airbag	X	X	X	X	X
NCML - Engine control module / NCML_17	X	X	X	X	X
NCMR - Engine control module / NCMR_17	X	X	X	X	X
NFR - Brake	X	X	X		X
OCTO unit left	X	X	X		X
OCTO unit right	X	X	X		X
On board charger	X	X	X		X
Parking sensor	X	X	X	X	X
Passenger interactive panel	X	X	X		X
Passive entry	X	X	X		X
Power control unit	X	X	X		X
Steering wheel	X	X	X		X
Surround view camera	X	X	X		X
Suspension	X	X	X		X
Tire pressure	X	X	X		X
Warning sound/ AVAS	X	X	X		X
Window lifter module left	X		X		X
Window lifter module right	X		X		X
eCall	X	X	X		X