

Injection-Valve Assembly

Table 13

Injection-Valve Assembly

Item	Description	HP Part Number
1	Injection-valve assembly, includes items 2 – 6	0101-0921
2	Rotor seal (Vespel)	0100-1853
	Rotor seal (Tefzel)	0100-1849
3	Stator head	0100-1850
4	Stator screws	1535-4857
5	Stator face	0100-1851
6	Isolation seal	0100-1852
	Hex key 9/64 inch (for stator screws)	8710-0060

Figure 30

Injection-Valve Assembly

