

## Parts

The following parts can be ordered for use in maintaining the optional high vacuum gauge. See the *Parts* chapter in the main body of this manual for additional parts.

---

Description	HP Part Number
Complete high vacuum system (includes gauge controller, ion gauge tube, controller cable, power cord, tee fitting, KF25 clamp and KF25 O-ring assembly)	HP 59822B #071
Controller cable (gauge controller to gauge tube)	59822-60002
Fuses	
0.60 A slow-blow	-----
1.25 A slow-blow	-----
Gauge controller	59822-60003
Ionization gauge tube	0960-0376
KF25 clamp	0100-0549
KF25 O-ring assembly	3162-0110
Tee fitting	05971-20580
Tube kit for HP 5971A (includes ion gauge tube, tee fitting, KF25 clamp and KF25 O-ring assembly)	59822-60071

---