
Outlet Ball Valve Assembly

Table 19

Outlet Ball Valve Assembly

Item	Description	HP Part Number
	Outlet ball valve — complete assembly	G1312-60008
1	Socket cap	G1312-21208
2	Housing screw	01018-22410
3	Outlet valve cartridge	No part number
4	Sieve (pack of 10)	5063-6505
5	Gold seal, outlet	5001-3707
6	Cap*	5062-2485

*Reorder number (pack of 4)

Figure 43

Outlet Ball Valve

