

Micro Flow Cell**Micro Flow Cell****Table 13****Repair Parts: Micro Flow Cell Assembly**

Item	Description	HP Part Number
	Micro flow cell assembly, 6 mm, 1.7 μ l, maximum pressure 400 bar	G1315-60015
1	Window assembly, comprises items 2, 3, 4, 5 and 6	
2	Seal ring	79883-27101
3	Quartz window	1000-0953
4	Compression washer	79883-28802
5	Spring washers (pack of 10)	5062-8553
6	Window screw	79883-22404
7	Capillary IN (0.12 mm, 290 mm lg) including heat exchanger	G1315-87325
8	Capillary OUT (0.12 mm, 290 mm lg)	G1315-87306
9	Clamp unit	G1315-84901
	Screw M 2.5, 4 mm lg for cell body/clamp unit	0515-1056
	Capillary 0.12 mm, 150 mm lg)	G1315-87312
	Capillary 0.17 mm, 380 mm lg)	G1315-87311
	Cell Repair Kit HP, includes 1 quartz window, 5 spring washers, 2 seal rings	79883-68700

Identifying Parts and Materials
Micro Flow Cell

Figure 42

Micro Flow Cell Assembly Parts

