

## Leak Parts

**Table 23**

**Leak Parts**

| Item | Description                                     | HP Part Number |
|------|---|----------------|
| 1    | Leak sensor assembly                            | 5061-3356      |
| 2    | Leak pan  | G1315-45501    |
| 3    | Leak funnel                                     | 5041-8388      |
| 4    | Leak funnel holder                              | 5041-8389      |
| 5    | Clip  | 5041-8387      |
| 6    | Leak Tubing 120 mm lg                           | 0890-1711      |
| 7    | Waste Tubing 1200 mm lg (part of accessory kit) | 0890-1711      |

**Figure 52**

**Leak Parts**

