


# Bottle Holder Assembly

**Table 4-6. Bottle Holder Assembly**

Item	Description	Part Number
1	Base Bottle	01090-07703
2	Shaft Long	01090-26103
3	Shaft Short	01090-26104
4	Rail	01090-43701
5	Catch	01090-45001
6	Helium Outlet	01090-67602
8	Retainer	0510-0045
9	Retainer	0510-0045
10	Grommet	0400-0002
11	Screw M3×0.5 - 6lg	0515-0536
12	Screws for securing bottle holder assembly to mainframe	0515-0898
	Plug Helium Inlet Cap. (isocratic or binary)	01090-23701



**Figure 4-6. Bottle Holder Assembly**