
Cable Overview

WARNING

Never use cables other than the ones supplied by Hewlett-Packard to ensure proper functionality and compliance with safety or EMC regulations.

Table 22**Cables Overview**

Type	Description	HP Part Number
Analog cables	HP 3390/2/3 integrators	01040-60101
	HP 3394/6 integrators	35900-60750
	HP 35900A A/D converter	35900-60750
	General purpose (spade lugs)	01046-60105
	HP 3390/2/3 integrators	01040-60101
Remote cables	HP 3390 integrator	01046-60203
	HP 3392/3 integrators	01046-60206
	HP 3394 integrator	01046-60210
	HP 3396A (Series I) integrator	03394-60600
	HP 3396 Series II / 3395A integrator, see page 178	
	HP 3396 Series III / 3395B integrator	03396-61010
	HP 1050 modules / HP 1046A FLD	5061-3378
	HP 1046A FLD	5061-3378
	HP 35900A A/D converter	5061-3378
	HP 1040 diode-array detector	01046-60202
	HP 1090 liquid chromatographs	01046-60202
	Signal distribution module	01046-60202

Cable Overview**Table 22**

Cables Overview, continued		
Type	Description	HP Part Number
BCD cables	HP 3392/3 integrators	18594-60510
	HP 3396 integrator	03396-60560
	General purpose (spade Lugs)	18594-60520
Auxiliary	HP 1100 Series vacuum degasser	G1322-61600
CAN cables	HP 1100 module to module, 0.5m lg	5181-1516
	HP 1100 module to module, 1m lg	5181-1519
	HP 1100 module to control module	G1323-81600
External contacts	HP 1100 Series interface board to general purpose	G1103-61611
HP-IB cables	HP 1100 module to ChemStation, 1 m	10833A
	HP 1100 module to ChemStation, 2 m	10833B
RS-232 cable	HP 1100 module to a computer This kit contains a 9-pin female to 9-pin female Null Modem (printer) cable and one adapter.	34398A