

Table 12

---

<b>Fuses and circuit breakers</b>	
<b>Description</b>	<b>HP part number</b>
Circuit breaker (main power switch)	
110/120 V ac	3105-0172
220/240 V ac	3105-0173
Diffusion pump fuses	
2-amp (220/240 V ac)	2110-0002
4-amp (110/120 V ac)	2110-0055

---

Table 13

---

<b>Printed circuit boards</b>	
<b>Description</b>	<b>HP part number</b>
HP-IB/MS control card	05990-69406
Main board	05972-69020
Parallel/remote board (HP 5890 GC only – installed on the GC)	05990-60320
Power distribution board	05971-60003
Power supply	0950-2552
Status display (not shown)	05972-60030
Top board	05971-69001

---

