

Consumables

Consumables are supplies which are regularly used up during normal MSD operation or maintenance. This table lists consumables for the MSD. If there is a part you need that is not listed in this chapter, contact your Hewlett-Packard Customer Engineer or your local Hewlett-Packard office.

Description	HP Part Number
Abrasive paper, 30 μ m	5061-5896
Alumina powder	8660-0791
Cable ties	1400-0482
Cloths, clean	05980-60051
Cotton swabs (package of 100)	5080-5400
Diffusion pump fluid (20 ml)	6040-0723
Ferrules	
blank, graphite-vespel	0100-0691
0.1 7-mm id, for restrictor column	0100-0698
0.30l-mm id, for narrow-bore column	0100-1295
0.44-mm id, for wide-bore column	0100-0636
0.70-mm id, for megabore column	0100-1186
Filament assembly	05971-60140
Foreline pump fluid (1 liter)	6040-0517
Foreline trap pellets	9301-1104
Fuse	
diffusion pump	
2-amp (220/240 V ac)	2110-0002
4-amp (110/120 V ac)	2110-0055
power supply	
1-amp (220/240 V ac)	2110-0001
2-amp (110/120 V ac)	2110-0002

continued

Description	HP Part Number
Gloves, clean	
large	8650-0030
small	8650-0029
Hydrocarbon sample kit	05970-60045
O-rings and seals	
KF10 O-ring assembly	0100-1183
KF25 O-ring assembly	3162-0110
KF40 O-ring assembly	0100-1425
NW25 seal, vented	0100-1551
NW50 seal	05971-20177
top plate	05971-40100
PFTBA sample kit	05971-60571
Teflon tape	0460-0016
Vacuum gauges	
ionization gauge tube	0960-0376
foreline gauge tube	0960-0540
