Manual inlet flow manifold carrier (G1585A Accessory)

Description		HP Part No.	Qt y.
1.	Pneumatic Carrier Assembly	G1530-60950	1
2.	Screw, M4x25 mm, Torx T-20	0515-2712	2
3.	Screw, M4x12 mm, Torx T-20	0515-2496	4
4.	Chemical Trap Bracket	05890-00810	1
5.	Screw, M4 x10 mm, Torx T-20, Flathead	0515-2725	2
6.	Flow Side Cover	G1530-01240	1




Figure 1330-3 Manual inlet flow manifold carrier