

Table 11

---

**Printed circuit boards**


---

<b>Description</b>	<b>HP part number</b>
Electronics module, 120V	G1099-69222
Electronics module, 240V	G1099-69223
ac board	G1099-69003
fan for electronics module <sup>1</sup>	3160-1038
high voltage (HED) power supply	G1099-80017
HP-IB/MS control card	05990-69410
30-pin SIMM (2 required)	1818-4271
72-pin SIMM (1 required)	1818-5709
low voltage (ac-dc) power supply	0950-3067
main board	G1099-69010
signal amplifier board	G1099-69001
toroid transformer <sup>2</sup>	G1099-60229
Side board	G1099-69016
Turbo pump controller	G1099-89002

---

- 1 None of the parts in this table are user-replaceable parts. Refer service to your Hewlett-Packard service representative.
- 2 The toroid transformer is plugged into to one of two sockets on the AC board, depending on input line voltage.

