

## Manual Injector Parts ID

---

### Injector Module

Table 26-1. Injector Module

Item	Description	Part Number
1	Panel Top <i>Series I</i>	01090-04127
	Panel Top <i>Series II</i>	01090-04138
2	Panel Bottom <i>Series I</i>	01090-04128
	Panel Bottom <i>Series II</i>	01090-04139
3	Panel Front <i>Series I</i>	01090-00213
	Panel Front <i>Series II</i>	01090-00220

# Manual Injector




Figure 26-1. Injector Module