

Metering Pump and Rotary Valve

Table 20-5. Metering Pump and Rotary Valve

| Item | Description | Part Number |
|------|---|-------------|
| | Metering Pump <i>without rotary valve</i> | 79835-69020 |
| 1 | Coupler | 1500-0647 |
| 2 | Coupler | 1500-0648 |
| 3 | Seal | 0905-0989 |
| | Seal, pack of 4 | 5062-2494 |
| | Seal for use with buffered solvents | 0905-1194 |
| 4 | Thumbscrew | 5021-1840 |
| 5 | Plunger Guide | 79835-43101 |
| | Screws for plunger guide | 0515-0894 |
| 6 | Spring | 1460-1998 |
| 7 | Head Assembly ¹ | 79835-68101 |
| | Head Fixing Screw (metal housing) | 0515-0050 |
| | Head Thumb Screw (plastic housing) | 5021-1840 |
| 8 | Sapphire Plunger | 3980-0672 |
| | Ball Bearing for plunger | 1410-0075 |
| 9 | Rotary Valve | 79835-69021 |
| 10 | Wiper for opto sensor | 79835-44801 |
| 11 | Valve holder, metal ² | 79835-22305 |
| | Plastic cover for metering pump | 79835-44103 |

1 Complete assy. Consists of items 3,6,7,8

2 For pumps with metal housing only.




Figure 20-3. Metering Pump and Rotary Valve