
Outlet Ball Valve Assembly

Table 18

Outlet Ball Valve Assembly

Item	Description	HP Part Number
	Outlet ball valve — complete assembly	01018-60008
1	Socket cap	01018-25209
2	Housing screw	01018-22410
3	Outlet valve cartridge	No part number
4	Gold seal, outlet	5001-3707
5	Cap*	5062-2485

*Reorder number (pack of 4)

Figure 39

Outlet Ball Valve Assembly

