## Hydraulic Path without Solvent Selection Valve

## Table 11

## Hydraulic Path without Solvent Selection Valve

ltem	Description	HP Part Number
1	Capillary, mixer to purge valve	G1312-67308
2	Capillary, outlet ball valve to piston 2	G1312-67300
3	Mixer	G1312-87330
4	Bottle-head assembly	G1312-68706
5	Capillary, damper to mixer	G1312-67307
6	Restriction capillary	G1312-67304
7	Mixing capillary	G1312-67302
8	Capillary, pump to injection device	G1312-67305
9	Waste tube, 5 m	5062-2461
10	Adapter, AIV to bottle-head assembly	0100-1847
*	Capillary, damper to purge valve	G1312-67301

\* Capillary needed when pump used without mixer installed

## Parts and Materials Hydraulic Path without Solvent Selection Valve

Figure 35 Hydraulic Path without Solvent Selection Valve

