
Hydraulic Path

Table 10**Hydraulic Path**

Item	Description	HP Part Number
1	Capillary, piston 1 to damper	G1311-67301
2	Bottle-head assembly	G1312-68706
3	Capillary, damper to piston 2	G1311-67300
4	Outlet capillary, pump to injector device	G1312-67305
5	Waste tube, 5 m	5062-2461
6	Adapter, AIV to solvent inlet tubes	0100-1847

Figure 31**Hydraulic Flow Path of the Isocratic Pump**