

---

## Power and Status Light Pipes

**Table 14**

**Power and Status Light Pipes**

Item	Description	HP Part Number
1	Power switch coupler	5041-8383
2	Light pipe — power switch	5041-8382
3	Power switch button	5041-8381
4	Light pipe — status lamp	5041-8384

**Figure 35**

**Power and Status Light Pipes**

