

Foam Parts

Table 14

Foam Parts

Item	Description	HP Part Number
1	Board guide	5041-8395
2	Foam kit, including upper and lower foam	G1312-68702
3	Bushing, for pump drive	1520-0404

Figure 38

Foam Parts

