

MICRON – GRIND, DENSIFY, SEAL & BURNISH – TERRAZZO & CONCRETE

Category: Micron

System: Micron - Grind, Densify, Seal & Burnish - Terrazzo & Concrete

Products: Densi-Prime & Stone, Terrazzo and Concrete Seal

(Densi-Prime is only used with cement based surfaces)

Surfaces: Terrazzo, Concrete



- 1)** This System incorporates the use of a planetary machine with diamond tooling. Regardless of what diamond tooling one starts with, the use of the planetary grinder with this NeverStrip System ends with 150 hybrid or 200/400 resin diamonds.
- 2)** Remove dust created by planetary machine.
- 3)** Apply NeverStrip Densi-Prime at 1,500 sq. feet per gallon.
- 4)** Wait 30 minutes.
- 5)** Repeat Step 2.
- 6)** Wait 30 minutes.
- 7)** Burnish after the second application of Densi-Prime. Use an electric or propane burnisher. A higher rpm burnisher will produce more shine. A propane burnisher will produce the highest shine. Burnish with a NeverStrip Shine Diamond Encrusted Pad.
- 8)** Tack the floor with 3M Easy Trap Duster or equivalent to remove burnishing dust.

Continued on next page



neverstrip.com

MICRON – GRIND, DENSIFY, SEAL & BURNISH – TERRAZZO & CONCRETE

9) Apply Stone, Terrazzo and Concrete Seal at 4,000-5,000 sq. feet per gallon. Spray product onto the microfiber pad to make it damp. Apply a mist of product onto the section just before the product is spread with a standard microfiber pad. Do sections 3' x 4' or 3' x 5' at a time. If one person is spraying and one person is spreading, then the spraying should be “just before” the person spreads in the section. Do NOT Apply too much product onto the floor. If the product is “White” when you spread the product, then there is too much of the sealer applied to the floor. Do NOT Pull Product from one section onto another. Do NOT overwork the product. Do spread product onto adjoining sections by a couple of inches to avoid skips. Do allow 10 to 15 minutes for the product to dry before applying the next application, to burnish, or to allow typical commercial traffic to resume.

An alternative application method is to use a [Spray Microfiber Floor Mop](#) with a quart bottle on the stem and a trigger at the top of the pole to release a spray in front of the microfiber pad. Typically, two sprays is an appropriate amount of sealer to spread across an area 18” wide and 36” forward.

10) Wait 20 minutes.

11) Burnish with a NeverStrip Shine Pad.

12) Tack the floor

13) Repeat Steps 9, 10 and 11.

Caution: Keep water off the floor for 8 hours.

Scrubbing the floor with a red pad and Micron Clean (2 oz./gallon of water), then burnishing during the first week or two after application is a best practice for removing marks/scuffs/surface scratches from the sealer during its initial curing.

Additional instructions on Product Data Sheets and other resources are available at www.neverstrip.com.

Cleaning and Maintenance: Click [here](#).



neverstrip.com