

# MICRON CLEAN & SEAL – RESILIENT (LVT, LINOLEUM, SHEET VINYL, BBT, RUBBER)

**Category:** Micron

**System:** Micron Clean & Seal – Resilient

**Products:** Vinyl Seal or Rubber Seal

**Surfaces:** Resilient Flooring



- 1)** Thoroughly strip and clean the substrate of any floor finish, soil, grease, etc.
- 2)** Apply Vinyl Seal onto a small area of the floor. If the sealer separates like oil and water or has fish-eyes, then the floor's surface tension will not allow the sealer's application. Unlike ceramic flooring, the surface tension of the resilient flooring can be modified to allow for the application of the sealer. Dry condition the resilient floor with a NeverStrip Enhanced Prep Pad or Maroon X Restoration Pad, using a 175-rpm or Square Scrub type machine. Scrub and extract the floor after the conditioning process.
- 3)** Apply 2-3 applications of Vinyl Seal on non-rubber resilient flooring. Apply 2-3 applications of Rubber Seal on rubber flooring. The spread rate is 4,000-5,000 sq. feet per gallon per application. Spray product onto the microfiber pad to make it damp. Apply a mist of product onto the section just before the product is spread with a standard microfiber pad. Do sections 3' x 4' or 3' x 5' at a time. If one person is spraying and one person is spreading, then the spraying should be "just before" the person spreads in the section. Do NOT Apply too much product onto the floor. If the product is "White" when you spread the product, then there is too much of the sealer applied to the floor. Do NOT Pull Product from one section onto another. Do NOT overwork the product. Do spread product onto adjoining sections by a couple of inches to avoid skips. Do allow 10 to 15 minutes for the product to dry before applying the next application, to burnish, or to allow typical commercial traffic to resume.

**Caution:** Keep water off the floor for 8 hours.

An alternative application method is to use a [Spray Microfiber Floor Mop](#) with a quart bottle on the stem and a trigger at the top of the pole to release a spray in front of the microfiber pad. Typically, two sprays is an appropriate amount of sealer to spread across an area 18" wide and 36" forward.

Scrubbing the floor with Micron Clean (2 oz./gallon of water) and a red scrubbing pad during the first week or two after application can be a good practice for removing marks/scuffs/surface scratches from the sealer during its initial curing.

Additional instructions on Product Data Sheets and other resources are available at [www.neverstrip.com](http://www.neverstrip.com).

**Cleaning and Maintenance:** Click [here](#) for instructions.



[neverstrip.com](http://neverstrip.com)